

Replacing the 0714 and 0714E Strap Mount screws and Hook 'n Loop strip



1. Carefully clip tie securing Cushion Insert.



2. Pull back Cushion Insert revealing Strap Mount screws and Hook 'n Loop.



3. Cut Hook 'n Loop where the 2 frame parts meet.



4. Remove Hook 'n Loop strip where the 2 frame parts meet.



5. Remove Strap Mount screws.



6A. Replace with new Strap Mount screws. (Note 2 different size screws and placement).



6B. Tighten screws.



7. Cut new Hook 'n Loop strip from kneeseat to end of Strap Mount (Note: New Hook 'n Loop strip approx. 1.5" longer than old)



8. Firmly press Hook 'n Loop strip onto frame and over screw heads and then re-secure Cushion with supplied cable tie.