

## Ordering in 4 Simple Steps


**1. Remove shoe.**

**2. Measure from floor (A) to top of kneecap (B), while standing.**


Round **DOWN** to the nearest size  
(Example, if you measure 21 ¼ select 21.5)

**3. Measure around widest part of your calf muscle (C), with work pants on.**

Round **UP** to the nearest size  
(Example, if you measure 13 ¼ select 13.5)



A to B Measurement is



**Incorrect**      **Correct**


C Measurement is



**Incorrect**      **Correct**



**Which width you receive is determined by the "C" Measurement - 17.5" or larger **DEFAULTS** to Model 0714E<sup>®</sup> WIDE**



### 4. **1" VS 5/8" FOAM INSERTS**

Over 75% of our customers prefer  1" Foam Inserts!

We recommend 1" if the following conditions apply:

- If you are working on your knees at least 8 hours per day
- If you have had any knee problems or surgery
- If you weigh more than 200 lbs
- If you prefer the maximum protection that ProKnee<sup>®</sup> has to offer

### **5/8" STANDARD      5/8" WIDE**



### **1" STANDARD**

### **1" WIDE**

