




AP16[®] Upgrading the AP16 ALL PURPOSE KNEEPADS Cushion Insert from 5/8" to 1"




1. Remove all 6 screws securing the boot to the frame.




2. Remove and discard old liner.




3. Remove Cushion Insert by carefully clipping both Cable Ties that secure the Cushion to the frame.




4. Remove old 1 1/2" x 10 3/4" Hook 'n Loop from frame. (Leave all stapled 1/2" Hook 'n Loop in place)




5. Line up replacement Hook 'n Loop and stick to the bottom front of the frame.




6. Replacement Hook 'n Loop will wrap around to the top of the frame.




7. Line up Cable Tie holes on frame and Cushion. Thread Cable Tie through the left hole and up through the Cushion Insert.




8. Then thread Cable Tie down through the right hole of the Cushion.




9. Thread through Cable Tie end and pull.



10. Tighten Cable Tie with pliers.



11. Carefully clip off excess Cable Tie and install new 1" liner. Refer to "Replacing the AP16 No Wrinkle Liner" on back, if needed.



12. Replace all 6 screws securing the boot to the frame.